

















MONTAGEANLEITUNG
INSTRUCTIONS DE MONTAGE
ASSEMBLY INSTRUCTIONS
MONTAGEAANWIJZING














181	4		
190	8		∅ 8 x 30mm
220	8		
320	8		6 x 50mm
350	4		3,5 x 25mm
740	2		
741	2		∅ 8 x 60mm
818	1		L
819	1		R

















3.




4.



5.



6.



7.

