




















MONTAGEANLEITUNG
INSTRUCTIONS DE MONTAGE
ASSEMBLY INSTRUCTIONS










150	4	
154	4	
187	20	
190	8	 Ø8 x 30 mm
220	12	
245	2	
320	19	 6 x 50 mm
351	12	 3,5 x 15 mm
352	6	 4 x 20 mm
377	2	 4 x 25 mm
503	1	
737	6	





1 + 2











3



















9



9



4X

