










# NÁVOD NA MONTÁŽ CT-622

A		C		E		G							
	4 KS		4 KS		1 KS		4 KS						
B		D		F									
	4 KS		4 KS		4 KS								


①



②



③



④

