


























# ARCO

									
① X 1	② X 1	③ X 1	④ X 1	⑤ X 1	⑥ X 1	⑦ X 3	⑧ X 1		
									
⑨ X 1	⑩ X 1	A X 25 M8 x 30mm	B X 6 M8 x 35mm	C X 1 M8 x 45mm	D X 32 M8	E X 2	F X 1 #6	G X 1 #3	
MCA 				MCA 				VERSION 2	
									
									
D Bitte überprüfen Sie in regelmäßigen Abständen den festen Sitz der Schrauben!				NL Controleer op regelmatige afstanden of de schroeven goed vast zitten.					
GB Please check the screws for tightness at regular intervals!				SWE Kontrollera med jämna mellanrum att skruvarna sitter fast ordentligt!					
F Veuillez contrôler régulièrement le serrage des vis!				SK V pravidelných intervalech kontrolujte pevné dotiahnutie skrutiek!					
ES Compruebe periódicamente que los tornillos estén bien apretados!				SL Redno preverjajte, ali so vijaki trdno priviti!					
IT Controllare regolarmente che le viti siano ben strette!				HR Redovito provjeravajte čvrsto nalijezanje vijaka!					
PL Należy regularnie sprawdzać dokręcenie śrub!									

VERSION 1



VERSION 2

